



















MF8604 Quick Start Guide

Product Safety Information

For more information, please read the user manual stored in the preinstalled microSD card.

	Read the Safety Information section of this Quick Start Guide on this page		Do not use while re-fuelling
	Do not use hand-held while driving		This device may produce a bright or flashing light
	For body-worn operation maintain a separation of 15 mm		Do not dispose of it in a fire
	Small parts may cause a choking hazard		Avoid contact with magnetic media
	This device may produce a loud sound		Avoid Extreme Temperatures
	Keep away from pacemakers and other personal medical devices		Avoid any contact with liquid, keep it dry
	Switch off when instructed in hospitals and medical facilities		Do not attempt to disassemble


	Switch off when instructed in aircrafts and airports		Do not rely on this device for emergency communications
	Switch off in explosive environments		Only use approved accessories

Notes:

microSD logo  is a trademark of the SD Card Association.

CE 1588 !

Getting to know your phone



Power Key

- Hold to select phone modes: Silent, Vibration, Airplane, or to power off.
- Press to switch your phone to Sleep mode.
- Press to wake up your phone.

Home Key

- Press to return to the Home Screen from any application or screen.
- Hold to see recently used applications.

Menu Key

Press to get the options on the current screen.

Back Key


Press to go to the previous screen.

Volume Key


Press higher end of the key to turn the volume up and the lower end of the key to turn it down.

Before getting started


Removing the back cover




Installing the SIM card




Installing the battery



Installing the memory card



Charging the battery



When you first get your new phone you'll need to charge the battery like this...

1. Connect the adapter to the charger jack.
2. Connect the charger to a standard AC wall outlet.
3. Disconnect the charger when the battery is fully charged.

Powering on/off your phone

1. Make sure the SIM is in your device and the battery is charged.
2. Hold **Power Key** to switch on your phone.
3. To switch it off, hold **Power Key** to get the phone options. Select **Power off**, and then tap **OK**.


Switching to sleep mode

To save battery power, Sleep Mode suspends your device to a low-power-consumption state while the display is off. Your device also goes into Sleep Mode automatically when the display is automatically turned off after a certain period of time, which you can set in **Screen timeout** of the display settings.

Press **Power Key** to switch to Sleep Mode.

Waking up your phone

If your phone is in Sleep Mode, you can wake it up by:

1. Pressing **Power Key** to activate your screen display.
2. Drag the  icon to the right.

Notes:

If you have set an 'unlock pattern' for your phone, you'll need to draw the pattern to unlock your screen.