



My Surf pure powered by Android™



Quick Start Guide

LEGAL INFORMATION

Copyright © 2012 ZTE CORPORATION.

All rights reserved.

No part of this publication may be quoted, reproduced, translated or used in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation.

ZTE Corporation reserves the right to make modifications on print errors or update specifications in this guide without prior notice.

The Bluetooth® trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such trademarks by ZTE Corporation is under license. Other trademarks and trade names are the property of their respective owners.

The phone is manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.

We offer self-service for our smart terminal device users. Please visit ZTE official website (at www.zte.com.cn) for more information on self-service and supported product models. Information subject to the website.


CE 1588

Version No. : R1.0

Edition Time : 20120428

Manual No. : 079584504586

Getting to Know Your Phone



ZTE

ZTE CORPORATION

NO. 55, Hi-tech Road South, ShenZhen, P.R.China

Postcode: 518057


<http://www.zte.com.cn> mobile@zte.com.cn

Service Hotline: +86-755-26779999


The information on the package is only for your reference. Images are for your reference only. Please check the product model before purchasing. ZTE reserves the right to change specifications and parameters of the products without further notice.

Starting Up


Removing the back cover




Inserting the SIM card



Installing the microSD card



NOTE: microSD logo  is a trademark of the SD Card Association.
Installing the battery



Charging the phone



Powering On/Off Your Phone

Make sure the SIM is in your device and the battery is charged.

- Press and hold the **Power Key** to switch on your phone.
- To switch it off, press and hold the **Power Key** and touch **Power off > OK**.

Locking/Unlocking the Screen and Keys



Your phone allows you to quickly lock the screen and keys when not in use and to turn the screen back on and unlock it when you need it.

To lock the screen and keys:

To quickly turn the screen off and lock the keys, press the **Power Key**.

NOTE: To save battery power, the phone automatically turns off the screen after a certain period of time when you leave it idle. You will still be able to receive messages and calls while the phone screen is off.











To unlock the screen and keys:








1. Press the **Power Key** to turn the screen on.
2. Drag  to  to unlock the screen and keys.

You can also drag  to  to open the camera and start taking photos immediately.

NOTE: If you have set an unlock pattern, PIN or password for your phone, you'll need to draw the pattern or enter the PIN/password to unlock your screen.

Product Safety Information

	Do not use handheld while driving		Do not use while re-fuelling
	For body-worn operation maintain a separation of 15 mm		This device may produce a bright or flashing light
	Small parts may cause a choking hazard		Do not dispose of it in a fire
	This device may produce a loud sound		Avoid contact with magnetic media
	Keep away from pacemakers and other personal medical devices		Avoid Extreme Temperatures

	Switch off when instructed in hospitals and medical facilities		Avoid any contact with liquid, keep it dry
	Switch off when instructed in aircrafts and airports		Do not attempt to disassemble
	Switch off in explosive environments		Only use approved accessories
	Do not rely on this device for emergency communications		