

MF669

Quick Guide

The ZTE USB modem is a multi-mode USB modem, working in HSPA+/HSPA/WCDMA/EDGE/GPRS/ GSM networks. With USB interface connecting to a laptop or a desktop PC, it integrates the functionality of a modem and a mobile phone (SMS), and combines mobile communication with Internet perfectly. It supports data and SMS services through the mobile phone network, enabling you to communicate

anytime and anywhere. **Specification**

The following table shows the specification of your device.


5 · · · · · · · · · · · · · · · · · · ·	
erface Type	USB 2.0 HIGH SPEED
stems supported	Supports most types of laptop and desktop PC.
erating systems supported	Windows XP(SP2 or later), Vista(32bit or 64bit), Windows 7
	MAC 10.4 or later

ns Ctandarda	SMS service, Data service, Applications management, support microSD card, etc.
	· · · · · · · · · · · · · · · · · · ·
Standards	HSPA+/HSPA/WCDMA/EDGE/GPRS/GSM
ssion speed (Max)	HSUPA: 5.76 Mb/s UL
	HSPA+: 21.6 Mb/s DL
ature	Storage: -20 °C ~ +70 °C
	Operation:-10 °C ~ +60 °C
on	90 mm×27 mm×12.5 mm(without cap)
	About 28 g
) capacity	Up to 32 G

Notes: microSD **Micro** is a trademark of SD Card Association.

Getting to know your device

The following figure shows the appearance of the MF669. It is only for your reference. The actual product may be different.



- LED Indicator
- . Front Cover
- USB Connector
- 4. SIM/USIM card slot
- 5. External Antenna Jack
- microSD card slot

Notes: The modem only supports microSD card.

Hardware Installation

the front cover.

1. Put finger on the bottom finger grip, and then lift the front cover of the modem to release and remove.



Notes: Do not open the front cover rudely to avoid the damage of

2. Insert the SIM/USIM card and microSD card.

Insert the SIM/USIM card with the metal contact area facing downwards into the slot, and then insert the microSD card, shown as the following picture.



LEGAL INFORMATION

Copyright © 2011 ZTE CORPORATION.

No part of this publication may be excerpted, reproduced, translated or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permis-

sion of ZTE Corporation.

The manual is published by ZTE Corporation. We reserve the right to make modifications on print errors

or update specifications without prior notice.

Version No.: R1.0

ZTE CORPORATION

NO. 55, Hi-tech Road South, ShenZhen, P.R.China

Postcode: 518057

Close the front cover as shown in the following picture.

- Plug the USB connector into your computer's USB port and









The OS will automatically recognize the new hardware and start the installation wizard.

Warning and Notice

To the owner

modem if required.

- Some electronic devices are susceptible to electromagnetic interference sent by modem if inadmance. equately shielded, such as the electronic system of vehicles. Please consult the manufacturer of the device before using the modem if necessary.
- Operating of laptop and desktop PCs and the modem may interfere with medical devices like hearsing your USB Modem ing aids and pacemakers. Please always keep them more than 20 centimeters away from such medical devices when they are turned on. Turn the modem off if necessary. Consult a physician or the manufacturer of the medical device before using the modem.
- Be aware of the usage limitation when using a modem at places such as oil warehouses or chemical factories, where there are explosive gases or explosive products being processed. Turn off your
- com terminals

- The use of electronic transmitting devices is forbidden in aircrafts, at petrol stations and in hospitals. Please observe and obey all warning signs and switch off your modem in these conditions.
- Do not touch the inner antenna area if not necessary. Otherwise it will affect your modem's perfor-
- Store the modem out of the reach of little children. The modem may cause injury if used as a toy.
- Do not touch the metallic parts of the modem so as to avoid a burn, when the modem is working.
- Please use original accessories or accessories that are authorized. Using any unauthorized accessories may affect your modem's performance, and violate related national regulations about tele-
- Avoid using the modem near or inside metallic structures or establishments that can emit electro-
- magnetic waves. Otherwise it may influence signal reception.
- The modem is not waterproof. Please keep it dry and store in a shady and cool place.

- Do not use the modem immediately after a sudden temperature change. In such case, it will produce dew inside and outside the modem, so don't use it until it becomes dry.
- Handle the modem carefully. Do not drop, bend or strike it. Otherwise the modem will be damaged.
- No dismantling by non-professionals and only qualified technicians can undertake repair work.
- Operating temperature range of -10 °C ~ +60 °C and humidity range of 5% ~ 95% are recommend-

- This warranty does not apply to defects or errors in the Product caused by:
- Reasonable abrasion.
- i. End User's failure to follow ZTE's installation, operation or maintenance instructions or proce-
- iii. End User's mishandling, misuse, negligence, or improper installation, disassembly, storage, servicing or operation of the Product.

- iv. Modifications or repairs not made by ZTE or a ZTE-certified individual.
- v. Power failures, surges, fire, flood, accidents, actions of third parties or other events outside ZTE's reasonable control.
- vi. Usage of third-party products, or usage in conjunction with third-party products provided that such defects are due to the combined usage.
- vii. Any other cause beyond the range of normal usage intended for the Product.

End User shall have no right to reject or return the Product, or receive a refund for the Product from

ZTE under the above-mentioned situations.

This warranty is End User's sole remedy and ZTE's sole liability for defective or nonconforming items, and is in lieu of all other warranties, expressed, implied or statutory, including but not limited to the implied warranties of merchantability and fitness for a particular purpose, unless otherwise required under the mandatory provisions of the law.

Limitation of Liability

ZTE shall not be liable for any loss of profits or indirect, special, incidental or consequential damages resulting from or arising out of or in connection with using of this product, whether or not ZTE had been advised, knew or should have known of the possibility of such damages, including, but not limited to lost profits, interruption of business, cost of capital, cost of substitute facilities or product, or any downtime

How to get help

- You can get Help by:
- Clicking Help on the software.
- Sending E-mail to mobile@zte.com.cn
- Visiting http://www.zte.com.cn

Calling Service Hotline: +86–755–26779999