

ZTE

Version No.: R1.0
Edition Time: 06.12.2010

LEGAL INFORMATION
Copyright © 2011 ZTE CORPORATION.
All rights reserved.
No part of this publication may be reproduced, reprinted, republished, translated or stored in a retrieval system without the prior written permission of ZTE Corporation. The content is published by ZTE Corporation. No content is to be reproduced or stored in a retrieval system without the prior written permission of ZTE Corporation.

Security

- To protect your mobile phone from illegal use, take the security measures as follows:
 - Set PIN codes of the SIM card.
 - Set handset lock code.
 - Set call restrictions.

Safety Precautions

This section includes some important information on safe and efficient operation. Please read this information before using the phone.

Operational Precautions

- Please use your phone properly. When making or receiving a call, please hold your phone as holding a wireless telephone. Make sure that the phone is at least one inch (about two point five centimeters) from your body when transmitting.
- Do not touch the antenna when the phone is in use. Touching the antenna area affects call quality and may cause the phone to operate at a higher power level than needed.
- Some people may be susceptible to electric seizures or blackouts when exposed to flashing lights, such as when watching television or playing video games. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your doctor before playing video games on your phone or enabling a flashing-light feature on your phone. (The flashing-light feature is not available on all products.)
- Keep the phone out of the reach of small children. The phone may cause injury if used as a toy.

Do not use a dry cloth or electrostatically charged cloth. Do not use chemical or abrasive cleaners as these could damage the phone.

- As your mobile phone can produce electromagnetic field, do not place it near magnetic items such as computer disks.
- Using the phone near electrical appliances such as TV, telephone, radio and personal computer can cause interference.
- Do not expose your mobile phone to direct sunlight or store it in hot areas. High temperatures can shorten the life of electronic devices.
- Keep your phone dry. Any liquid may damage your phone.
- Do not drop, knock or harshly treat the phone. Rough handling can break internal circuit boards.
- Do not connect the phone with any incompatible enhancement.
- Do not attempt to disassemble the mobile phone or battery.
- Do not store the phone with flammable or explosive articles.
- Do not charge the mobile phone without battery.
- Some electronic devices are susceptible to electromagnetic interference sent by phone if inadequately shielded. Please use phone at least 20 cm or as far away as you can from TV set, radio and other automated office equipment so as to avoid electromagnetic interference.
- Operating phone may interfere with medical devices like hearing aids and pacemakers, or other medical devices in hospital. Consult a physician or the manufacturer of the medical device before using phone.
- Be aware of the usage limitation when using phone at places such as oil warehouses, or chemical factories, where there are explosive gases or explosive products being processed, because even if your phone is in idle state, it still transmits radio frequency (RF) energy. Therefore, power off your phone if required.

Safety and General Use in Vehicles

- Safety airbag, brake, speed control system and oil sject system shouldn't be affected by wireless transmission. If you do meet problems above, please contact your automobile provider. Do not place your phone in the area over an airbag or in the airbag deployment area. Airbags inflate with great force. If a phone is placed in the airbag deployment area and the airbag inflates, the phone may be propelled with great force and cause serious injury to occupants of the vehicle.
- Please turn off your mobile phone at a refueling point, and the same to the place where the use of two-way radio is prohibited.

Aircraft Safety

- Please turn off your mobile phone before the airplane takes off. In order to protect airplane's communication system from interference, it is forbidden to use mobile phone in flight. Safety regulations require you to have permission from a crew member to use your phone while the plane is on the ground.
- If the mobile phone has the function of automatic timing power-on, please check your alarm setting to make sure that your phone will not be automatically turned on during flight.

Battery Use

- Do not short-circuit the battery, as this can cause the unit to overheat or ignite.
- Do not store battery in hot areas or throw it into fire. Otherwise, it will cause explosion.
- Do not disassemble or refill the battery. Otherwise, it will cause liquid leakage, overheating, explosion and ignition of the battery.
- Please store the battery in a cool dry place if you don't use it for a long period.

device while operating it typically below that indicated above. This is due to automatic changes to the power level of the device to ensure it only uses the minimum power required to communicate with the network.

* The tests are carried out in accordance with EN 62209-1.

Body Worn Operation

Important safety information regarding radiofrequency radiation(RF) exposure.

To ensure compliance with RF exposure guidelines the phone must be used with a minimum of 15 mm separation from the body.

Failure to observe these instructions could result in your RF exposure exceeding the relevant guideline limits.

Limiting Exposure to Radio Frequency (RF) Fields

For individuals concerned about limiting their exposure to RF fields, the World Health Organisation (WHO) provides the following advice:

Precautionary measures: Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If individuals are concerned, they might choose to limit their own or their children's RF exposures by limiting the length of calls, or using hands-free' devices to keep mobile phones away from the head and body.

Further information on this subject can be obtained from the WHO home page: http://www.who.int/tsp/enf/WHO_Fact_sheet_193_June_2000.

- Some electronic devices are susceptible to electromagnetic interference sent by phone if inadequately shielded. Please use phone at least 20 cm or as far away as you can from TV set, radio and other automated office equipment so as to avoid electromagnetic interference.
- Operating phone may interfere with medical devices like hearing aids and pacemakers,

content or services in a manner that has not been authorized by the content owner or service provider. Without limiting the foregoing, unless expressly authorized by the applicable content owner or service provider, you may not modify, copy, reupload, upload, post, transmit, translate, sell, create derivative works, exploit, or distribute in any manner or medium any content or services displayed through this device.

THIRD PARTY CONTENT AND SERVICES ARE PROVIDED "AS IS." ZTE CORPORATION DOES NOT WARRANT CONTENT OR SERVICES PROVIDED, EITHER EXPRESSLY OR IMPLIEDLY, FOR ANY PURPOSE. ZTE CORPORATION EXPRESSLY DISCLAIMS ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ZTE CORPORATION DOES NOT GUARANTEE THE ACCURACY, VALIDITY, TIMELINESS, LEGALITY, OR COMPLETENESS OF ANY CONTENT OR SERVICE MADE AVAILABLE THROUGH THIS DEVICE AND UNDER NO CIRCUMSTANCES, INCLUDING NEGLIGENCE, SHALL ZTE CORPORATION BE LIABLE, WHETHER IN CONTRACT OR TORT, FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, ATTORNEY FEES, EXPENSES, OR ANY OTHER DAMAGES ARISING OUT OF, OR IN CONNECTION WITH, ANY INFORMATION CONTAINED IN, OR AS A RESULT OF THE USE OF ANY CONTENT OR SERVICE BY YOU OR ANY THIRD PARTY, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

This party services may be terminated or interrupted at any time, and ZTE CORPORATION makes no representation or warranty that any content or service will remain available for any period of time. Content and services are transmitted by third parties by means of networks and transmission facilities over which ZTE CORPORATION has no control. Without limiting the generality of this disclaimer, ZTE CORPORATION expressly disclaims any responsibility or liability for any interruption or suspension of any content or service made available through this device. ZTE CORPORATION is neither responsible nor liable for customer service related to the content and services. Any question or request for service relating to the content or services

Function	Description
Left soft key	Performs the function indicated at the left bottom of the screen.
Right soft key	Performs the function indicated at the right bottom of the screen.
Centre key	Press to confirm actions and make selections.
4-way Navigation keys	These keys (UP, DOWN, LEFT and RIGHT) allow for navigation through menus options and quick access to some function menus.
Send key	Press to dial a phone number or answer a call, or view the call history.
End/Power key	Press to end to the idle mode. Hold to switch on/off the phone.
QWERTY keyboard	Press to enter characters 0-9, the alphabets from a-z and symbols.

Note: In this User Manual, "press a key" means to press the key and release it, while "hold a key" means to press the key for at least two seconds and then release it.

Locking and Unlocking the Keypad

In idle screen, hold key to lock the keypad.
To unlock the keypad, press **Left soft key** and then press **Key**.

Locking the keypad can prevent unintentional operations on it. You can answer an incoming call with the regular operation when the keypad is locked.

ZTE中兴 GSM

ZTE-G R237m

English User Manual

Precautions While Driving

- Please pay attention to the traffic safety. Check the laws and regulations on the use of your phone in the area where you drive. Always obey them.
- Use hands-free function of the phone, if available.
- Pull off the road and park before making or answering a call if conditions require.

Precautions for Medical Devices and Facilities

- When using your phone near pacemakers, please always keep the phone more than eight inches (about twenty centimeters) from the pacemaker when the phone is switched on. Do not carry the phone in the breast pocket. Use the ear opposite the pacemaker to minimize the potential for interference. Switch off the phone immediately if necessary.
- Some phones may interfere with some hearing aids. In the event of such interference, you may consult your hearing aids manufacturer to discuss alternatives.
- If you use any other personal medical device, please consult the manufacturer of your device to determine if it is adequately shielded from RF energy.
- In those facilities with special demand, such as hospital or health care facilities, please pay attention to the restriction on the use of mobile phone. Switch off your phone if required.

Mobile Phone

- Please use original accessories or accessories approved by the phone manufacturer. Using any unauthorized accessories may affect your mobile phone's performance, damage your phone or even cause danger to your body and violate related local regulations about telecom terminals.
- Turn off your phone before you clean it. Use a damp or anti-static cloth to clean the phone.

Precautions for Potentially Explosive Atmospheres

- Switch off your phone prior to entering any area with potentially explosive atmospheres, such as fueling areas, fuel or chemical transfer or storage facilities.
- Do not remove, install, or charge batteries in such areas. Spark in a potentially explosive atmosphere can cause an explosion or fire resulting in bodily injury or even death.
- To avoid possible interference with blasting operations, switch off your phone when you are near electrical blasting caps, in a blasting area, or in areas posted "Turn off electronic devices." Obey all signs and instructions.

Precautions for Electronic Devices

- Some electronic devices are susceptible to electromagnetic interference sent by mobile phone if inadequately shielded, such as electronic systems of vehicles. Please consult the manufacturer of the device before using the phone if necessary.

- The battery can be recharged for hundreds of times, but it eventually wear out. When the operating time (talk time and idle time) is noticeably shorter than normal, it is time to replace it with a new one.
- Please stop using the charger and battery when they are damaged or show evidence of aging.
- Return the worn-out battery to the provider or dispose of it in accordance with environment regulations. Do not dispose of it in household rubbish.
- Please use original batteries or batteries approved by the phone manufacturer. Using any unauthorized batteries may affect your handset performance or may cause danger of explosion, etc.

Warning! If the battery is damaged, do not discharge it. If the leakage does come into contact with the eyes or skin, wash thoroughly in clean water and consult a doctor.

RF Exposure

Specific Absorption Rate (SAR)

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The guidelines use a unit of measurement known as Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2.0 W/kg and the highest SAR value for this device when tested at the ear was 1.42 W/kg. As mobile devices offer a range of functions, they can be used in other positions, such as on the body as described in this user guide.

As SAR is measured utilizing the device's highest transmitting power, the actual SAR of this

- or other medical devices in hospital. Consult a physician or the manufacturer of the medical device before using phone.
- Be aware of the usage limitation when using phone at places such as oil warehouses, or chemical factories, where there are explosive gases or explosive products being processed, because even if your phone is in idle state, it still transmits radio frequency (RF) energy. Therefore, power off your phone if required.
- Do not touch the antenna while calling. Otherwise it will affect the quality of calling and waste battery energy. The damaged antenna will cause slight burn while touching your skin.
- Keep phone out of the reach of small children. Phone may cause injury if used as a toy.
- Do not put other things on the terminal to avoid overheating radiator.
- Keep the antenna free from obstructions and position the antenna straight up. This will ensure best call quality.

Limitation of Liability

ZTE shall not be liable for any loss of profits or indirect, special, incidental or consequential damages resulting from or arising out of or in connection with using this product, whether or not ZTE had been advised, knew or should have known the possibility of such damages. The user should refer to the enclosed warranty card for full warranty and service information.

Note: The pictures and icons shown in the manual are just schematic drawings for demonstration of functions. If they are inconsistent with your handset, please take your handset as the standard. If the inconsistency exists in the manual because the handset function has some updated, please refer to the follow-up public information from ZTE.

Some content and services accessible through this device belong to third parties and are protected by copyright, patent, trademark and/or other intellectual property laws. Such content and services are provided solely for your personal non-commercial use. You may not use any

should be made directly to the respective content and service providers. Downloading album artwork to ZTE CORPORATION'S music player will cause manipulation, modification or alteration of that content. Download of album artwork without permission may constitute an infringement of the artist's copyright in the album artwork and for their moral rights.

ZTE CORPORATION does not accept and disclaims any liability for any copyright infringement or infringement of moral rights which may arise as a result of a User downloading album artwork to the ZTE CORPORATION music player. Users should ensure that they are permitted by the terms of their licence from a music/album artwork supplier to download and subsequently modify album artwork.

Key Functions

- Torch
- Headset interface
- Earpiece
- Charger interface
- Left soft key
- Send key
- Phonebook key
- 4-way Navigation keys and Centre key
- Right soft key
- End/Power key
- Messages key
- QWERTY keyboard

Interfer icons

Indicator	What it means	Indicator	What it means
	Signal strength		New SMS (enable bus but when ringing)
	GPRS		Missed call
	Silent		Battery status
	General		New MMS
	Outdoor		Roaming
	Meeting		Alarm clock set

Battery

The lithium ion battery of the mobile phone can be immediately used after unpacking.

Installing the battery

- Put the battery cover from the notch on the bottom and remove the cover.
- Insert the battery by aligning the gold-colored contacts with the contacts in the battery slot.
- Push down the upper section of the battery until it clicks into place.
- Replace the battery cover and close it gently until you hear a click.

Removing the battery

- Make sure that your mobile phone is switched off.
- Remove the battery cover.
- Pull the battery up and remove it from the mobile phone.

Inserting the SIM card

Insert the SIM card as follows:

- Make sure that the phone is switched off and the charger is disconnected from the phone.
- Turn the phone over and remove the battery cover.
- Remove the battery if it is already installed.
- Hold your SIM card with the cut corner oriented as shown and then slide it into the card holder with the metal contacts facing downward.
- Replace the battery first.
- Replace the battery cover.

Charging the battery

Your phone is powered by a rechargeable battery. For maximum battery performance, it is recommended that you first use up the battery power and then charge it completely. A new battery's full performance is achieved only after three complete charge and discharge cycles.

- Connect your travel adapter to the left side of your mobile phone as shown in the diagram.
- Connect the other end of the travel adapter to the mains socket.

When the battery is being charged, the display will show the animation of a battery being filled up. When the battery is fully charged, disconnect the charger.

Powering your phone on/off

You can make emergency calls without the SIM card inserted so long as you are in an area with network coverage.

Answer a call
Press the **Send key**.

End a call
Press the **End key**.

Make sure that you are in an area with sufficient coverage to make calls. The strength of the network signal is indicated on the Status Bar of the screen.

Sending and receiving messages

- Send a message
You can use your mobile phone to send and receive messages.
 - Go to **Menu—Messages—SMS/MMS—Write message**.
 - Write your message. For more information on input method, see section "Text Input". When you write an SMS, press **Options—Send to**, and edit the recipient. When you write an MMS, you can edit To, Cc, Bcc, Subject and content. In content field, you can select **Options** and then select to add picture, audio, bookmark text.

- Basic way to make a call
In idle screen, press the numeric keys to input the number and press the **Send key** to dial.
- Dial from the Phonebook
Go to **Menu—Phonebook**. Find the name of the person you want to call, and press the **Send key**.
- Make an emergency call
You can make emergency calls without the SIM card inserted so long as you are in an area with network coverage.
- Answer a call
Press the **Send key**.
- End a call
Press the **End key**.

Make sure that you are in an area with sufficient coverage to make calls. The strength of the network signal is indicated on the Status Bar of the screen.

Organizer

- Calendar
Enter Calendar, the calendar of the current month will be displayed on the screen and the current date will be marked by a background box in a special colour.
- Tasks

reminder and auto quick end.

Setting your phone

You can adjust various settings of your phone. Go to **Menu—Settings**.

- Phone settings: Set time and date and schedule power on/off, select language, set pref. input methods, display, greeting text and LCD backlight, etc.
- Network settings: Set to automatically or manually select network, and set the preferred networks.
- Security settings: Set security features to protect you from unauthorized use of your phone and SIM card.
- Connectivity: View data account.
- Restore factory settings: Enter the phone lock code to restore to the factory settings. Some personal information might be lost if you use this function, so be careful.

Note: You may be required to input the phone lock code in some of the security settings interfaces. The default lock code is 1234. Go to **Security settings—Change password—Phone password** to change the phone lock code.

In LHM, you can refresh your playlist, set storage, or make personal settings.

- Sound recorder
Go to **Options—New record** to record a sound clip. Go to **Options—Settings** to set preferred settings, file format and audio quality. Go to **Options—List** to view the sound clips you recorded.
- FM radio
With the radio, you can search for radio channels, listen to them, and save them on your device. Note that the quality of the radio broadcast depends on the coverage of the radio station in that particular area. In the FM radio interface, you can press the **UpDown keys** to adjust volume, press the **Left/Right keys** to tune the frequency, and press the **Centre key** to pause. Select **Options** to enter the submenu.

Extra

- Calculator
You can perform simple calculations. You can add, subtract, multiply or divide, and select M, %, MR, and MC to perform relevant operations. Note: This calculator has limited accuracy and rounding errors may occur, especially in long division.
- Currency converter
Your mobile phone provides you with basic functions of currency conversion. Input the Rate, select **OK** and input a figure in the Local field, and then press **OK** to get the result.
- Stopwatch
Use it to record the time.
- Flashlight

not provide the service, these functions can't be used.

- WAP
Your phone supports Wireless Application Protocol (WAP). You can get access to this service through your network provider. WAP lets you get information about news, weather forecasts and more.
- Go to Services—WAP. You can perform the following operations:
 - Homepage: Homepage is a WAP site you set in **Settings—Profiles**.
 - Bookmarks: Access your phone's preset websites. Select a bookmark and press **Go** to load the website or you can select **Edit, Send, Delete, Delete all** or **Add bookmark**.
 - Recent pages: Display the pages you've visited recently. Select an item and choose **Go** to visit the page again.
 - Input address: Input a URL and press **Options—Done** to visit the site.
 - Service inbox: Check the service information sent by your service provider.
 - Settings: You can set Profiles, Browser options, Service message settings, Clear cache or Clear cookies.
- License manager
 - License list: Display the list of Licences.
 - Status: Check the version and time.
 - Advance: Select **Sweep** to remove useless licences and reboot your phone.

collection facilities appointed by the government or the local authorities.

- The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.

For this product's recycling information based on WEEE directive, please send an e-mail to weee@zte.com.cn

EC DECLARATION OF CONFORMITY

It is hereby declared that following designated product:

Product Type: GSM Dual-band GPRS/Digital Mobile Phone
Model No.: ZTE-G R237m

Complies with the essential protection requirements of the Radio and Telecommunication Terminal Equipment Directive (EC Directive 1999/5/EC) and the Electromagnetic Compatibility Directive (2004/108/EC).

This declaration applies to all specimens manufactured identical to the samples submitted for testing/evaluation.

Assessment of compliance of the product with the requirements relating to the Radio and Telecommunication Terminal Equipment Directive (EC Directive 1999/5/EC) was performed by American TCB/Notified Body No. 1588). Based on the following standards:

Inserting the Memory Card

You can use memory card to expand the storage of the phone. You can store or copy files such as photos, music, and so on.

Do not take out the card or switch off the phone while transmitting or storing data, which may cause data loss or damage to the phone or the card.

Insert the memory card as follows:

- Alphabetic Modes
 - Press **A—Z** to enter desired characters.
 - Press **Space** to switch between uppercase and lowercase.
 - Press **Enter** to enter a space.
 - Press **Del** to delete letters left of the cursor.
- Numeric Mode
In numeric mode, use the numeric keys to enter numbers.
- Entering Symbols
press **Options—Input method—Insert symbol**, then select desired symbol. Or you can press **Del** first and then press the keys with the symbols you need on it.

Adding contact to the Phonebook

There are some numbers that you may want to call again and again, so it makes sense to add these numbers to your Phonebook. You can then access these numbers quickly and easily.

- Go to **Menu—Phonebook—Options—Add new contact**.
- Select to save the number to SIM or phone.
- Edit the information and confirm by selecting **Done—Yes**.

You can also save a number right after you've made or received a phone call or a text message from someone who is not yet in your Phonebook list.

- To delete someone from your Phonebook list, first select the name, then select **Options—Delete**.

Making and receiving calls

- attachment and side.
- When you finish writing an SMS, press **Done**, and select to send or save.

- Receive a message
Upon receiving a message, the mobile phone will alert you with a ringtone, prompt, or a new message icon.
- You can view the time in different cities.

Games

Go to **Menu—Fun&Games—Games**.

Your mobile phone has classic games. Select a game and start it, you can view **Help** to see the rules of the game.

Multimedia

Go to **Menu—Multimedia**.

- Image viewer
The images you want to view in Image viewer must be put in the **Photos** folder in the phone or memory card, and in **Options—Storage**, the storage must be set to phone or memory card correspondingly.
- Audio player
You can play the audio in your phone or memory card. The music you want to play in Audio player must be put in the **My Music** folder in the phone or memory card, and in **List—Options—Settings—Pre-playlist**, the storage must be set to phone or memory card correspondingly.

You can add tasks in this menu.

- Alarm
You can view, and edit the alarm clocks settings. You can also enable or disable the alarms. By tapping **Edit**, you can set the corresponding features of the alarm according to instructions: Repeat, Time, Alarm tone, Snooze, etc.
- World clock

You can view the time in different cities.

Press the **Centre key** or **Left soft key** to turn on or off the torch. Or you can hold the **UP key** to turn on or off the torch in idle screen.

File manager

Go to **Menu—File manager**. You can check all the folders in the phone or memory card, create new ones or rename, delete, or sort, etc. The files you download from the internet will be stored in these folders.

Note: When you select **Format**, the data will be lost, so please be careful with this function.

Camera

Go to **Menu—Camera**.

- Take a Photo
Go to **Camera** to take a photo. Aim the camera at the object and then press the **Centre key** to take the shot.
- Configure your camera
Go to **Camera**. Press the **Left soft key** to configure your camera.

Using Services

Services allows you to view internet content. In Services you can use the STK and WAP, and you can go to **License manager** to manage the licenses.

- STK
SIM card Toolkit (STK) services are value-added services provided by your network provider.
- Your mobile phone supports STK service, but if your SIM card and network provider do

Declaration of RoHS Compliance

To minimize the environmental impact and take more responsibility for the earth we live in, this document shall serve as a formal declaration that the ZTE-G R237m, manufactured by ZTE CORPORATION, is in compliance with the Directive 2002/95/EC of the European Parliament - RoHS (Restriction of Hazardous Substances) with respect to the following substances:

- Lead (Pb)
- Mercury (Hg)
- Cadmium (Cd)
- Hexavalent Chromium (Cr (VI))
- Polybrominated biphenyls (PBB's)
- Polybrominated diphenyl ethers (PBDE's)

... This declaration is issued based on our current level of knowledge. Since conditions of use are outside our control, ZTE CORPORATION makes no warranties, express or implied, and assumes no liability in connection with the use of this information.

Disposal of your old appliance

- When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/CE.
- All electrical and electronic products should be disposed of separately from the municipal waste stream via designated

Safety	EN60950-1:2006/A1:2009
EMC	EN 301 488-1 V1.8.1 EN 301 488-7 V1.3.1 EN 55013:2001/A2:2006 EN 55020:2007
Radio	EN 301 511 V9.0.2
Health	EN 50360:2001 EN 62209-1:2006 IEC 62209-2:2010 EN 62019-0:03 EN 50332-1:2000 EN 50332-2:2003

This declaration is the responsibility of the manufacturer:
ZTE Corporation

ZTE Plaza, Keji Road South, Hi-Tech, Industrial Park, Nanshan District, Shenzhen, Guangdong, 518057, P.R.China
Authorised person signing for the company:
Xu feng Quality Director Of ZTE Corporation

Names in block letters & position in the company
Shenzhen, 14th Feb 2011

Place & date Legally valid signature