

ZTE

GSM



ZTE-G ***R255***

English

User Manual

Security

- n To protect your mobile phone from illegal use, take the security measures as follows:
 - ∅ Set PIN codes of the SIM card.
 - ∅ Set handset lock code.

Safety Precautions

This section includes some important information on safe and efficient operation. Please read this information before using the phone.

Operational Precautions

- n Please use your phone properly. When making or receiving a call, please hold your phone as holding a wireline telephone. Make sure that the phone is about one inch from your body when transmitting.
- n Do not touch the antenna when the phone is in use. Touching the antenna area affects call quality and may cause the phone to operate at a higher power level than needed.
- n Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when watching television or playing video games. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your doctor before playing video games on your phone or enabling

a flashing-light feature on your phone. (The flashing-light feature is not available on all products.)

- n Keep the phone out of the reach of small children. The phone may cause injury if used as a toy.

Precautions While Driving

- n Please pay attention to the traffic safety. Check the laws and regulations on the use of your phone in the area where you drive. Always obey them.
- n Use hands-free function of the phone, if available.
- n Pull off the road and park before making or answering a call if conditions require.

Precautions for Medical Devices and Facilities

- n When using your phone near pacemakers, please always keep the phone more than eight inches (about twenty centimeters) from the pacemaker when the phone is switched on. Do not carry the phone in the breast pocket. Use the ear opposite the pacemaker to minimize the potential for interference. Switch off the phone immediately if necessary.
- n Some phones may interfere with some hearing aids. In the event of such interference, you may consult your hearing aids manufacturer to discuss alternatives.
- n If you use any other personal medical device, please consult the manufacturer of your device to determine if it is adequately shielded from RF energy.

- n In those facilities with special demand, such as hospital or health care facilities, please pay attention to the restriction on the use of mobile phone. Switch off your phone if required.

Mobile Phone

- n Please use original accessories or accessories approved by the phone manufacturer. Do not connect the phone with any incompatible enhancement.
- n Turn off your phone before you clean it. Do not use harsh chemicals, cleaning solvents, or aerosols to clean the device or its accessories.
- n Do not expose your mobile phone to direct sunlight or store it in hot areas. High temperatures can shorten the life of electronic devices.
- n Keep your phone dry. Any liquid may damage your phone.
- n Do not drop, throw or try to bend your phone or its accessories.
- n Do not attempt to disassemble the mobile phone or battery.
- n Do not charge the mobile phone without battery.
- n Some electronic devices are susceptible to electromagnetic interference sent by phone if inadequately shielded. Please use phone at least 20 cm or as far away as you can from TV set, radio and other automated office equipment so as to avoid electromagnetic interference.
- n Keep phone out of the reach of small children. Phone may

cause injury if used as a toy.

- n Do not put other things on the terminal to avoid overlaying radiator.
- n Do not connect the phone with any incompatible enhancement.
- n Keep the antenna free from obstructions and position the antenna straight up. This will ensure best call quality.

Precautions for Potentially Explosive Atmospheres

- n Switch off your phone prior to entering any area with potentially explosive atmosphere, such as fueling areas, fuel or chemical transfer or storage facilities.
- n Do not remove, install, or charge batteries in such areas. Spark in a potentially explosive atmosphere can cause an explosion or fire resulting in bodily injury or even death.
- n Power off your mobile phone or wireless device when in a blasting area or in areas posted power off “two-way radios” or “electronic devices” to avoid interfering with blasting operations.

Precautions for Electronic Devices

- n Some electronic devices are susceptible to electromagnetic interference sent by mobile phone if inadequately shielded, such as electronic system of vehicles. Please consult the manufacturer of the device before using the phone if necessary.

Safety and General Use in Vehicles

- n Safety airbag, brake, speed control system and oil eject system shouldn't be affected by wireless transmission. If you do meet problems above, please contact your automobile provider. Do not place your phone in the area over an airbag or in the airbag deployment area. Airbags inflate with great force. If a phone is placed in the airbag deployment area and the airbag inflates, the phone may be propelled with great force and cause serious injury to occupants of the vehicle.
- n Please turn off your mobile phone at a refueling point, and the same to the place where the use of two-way radio is prohibited.

Aircraft Safety

- n Switch off your wireless device whenever you are instructed to do so by airport or airline staff.
- n Consult the airline staff about the use of wireless devices on board the aircraft. If your device offers a 'flight mode', this must be enabled prior to boarding an aircraft.

Battery Use

- n Do not short-circuit the battery, as this can cause the unit to overheat or ignite.
- n Do not store battery in hot areas or throw it into fire. Otherwise, it will cause explosion.

- n Do not disassemble or refit the battery. Otherwise, it will cause liquid leakage, overheating, explosion and ignition of the battery.
- n Please store the battery in a cool dry place if you don't use it for a long period.
- n The battery can be recharged for hundreds of times, but it will eventually wear out. When the operating time (talk time and idle time) is noticeably shorter than normal, it is time to replace it with a new one.
- n Please stop using the charger and battery when they are damaged or show evidence of aging.
- n Return the worn-out battery to the provider or dispose of it in accordance with environment regulations. Do not dispose of it in household rubbish.
- n Please use original batteries or batteries approved by the phone manufacturer. Using any unauthorized battery may affect your handset performance or may cause danger of explosion, etc.


Warning: If the battery is damaged, do not discharge it. If the leakage does come into contact with the eyes or skin, wash thoroughly in clean water and consult a doctor.

Limitation of Liability

ZTE shall not be liable for any loss of profits or indirect, special, incidental or consequential damages resulting from or arising out of or in connection with using this product, whether or not ZTE had been advised, knew or should have known the possibility of such damages. The user should refer to the enclosed warranty card for full warranty and service information.

Note: The pictures and icons shown in the manual are just schematic drawings for demonstration of functions. If they are inconsistent with your handset, please take your handset as the standard. If the inconsistency exists in the manual because the handset function has been updated, please refer to the follow-up public information from ZTE.

Key Functions













Function	Description
Left soft key	Performs the function indicated at the left bottom of the screen.
Right soft key	Performs the function indicated at the right bottom of the screen.
Centre key	Press to confirm actions and make selections.
4-Way Navigation keys	These keys (UP, DOWN, LEFT and RIGHT) allow for navigation through menu options and quick access to some function menus.

Send key	Press to dial a phone number or answer a call, or view the call history.
End/Power key	Press to end a call. Press to exit to the idle mode. Hold to switch on/off the phone.
Alpha/numeric keys	Press to enter characters or alphabets, etc.

Note: In this User Manual, “press a key” means to press the key and release it, while “hold a key” means to press the key for at least two seconds and then release it.

Interface icons

Indicator	Description	Indicator	Description
	Signal strength		New SMS
	Earphones		Missed call
	Silent		Battery status
	General		New MMS
	Alarm clock set		Keypad locked

Locking and Unlocking the Keypad


In idle screen, press the **Left soft key** and then press the * **key** within two seconds to lock the keypad. The unlock method is the same.

Locking the keypad can prevent unintentional operations on it. You can answer an incoming call with the regular operation when the keypad is locked.

Installing the SIM/SD card and battery


Switch off your phone before installing or replacing the battery, SIM or memory card.

1. Pull the back cover from the notch on the bottom and remove it.




Remove the battery cover

2. Hold the SIM card with the cut corner oriented as shown and then slide it into the card holder with the metal contacts facing downward.



Insert the SIM card


3. Insert the card with the metal contacts facing down until it clicks to the right position.




Insert the Memory card

Note: You can use memory card to expand the storage of the phone.

4. Insert the battery by aligning the metal contacts with the contacts in the battery slot. Gently push down the battery until it clicks into place. Then Press the cover gently back into place until you hear a click.



Push down the battery





Replace the battery cover

Removing the battery

The lithium ion battery of the mobile phone can be immediately used after unpacking.


1. Make sure that your mobile phone is switched off.
2. Remove the back cover.
3. Pull the battery up and remove it from the mobile phone.



Charging the battery

Your phone is powered by a rechargeable battery. For maximum battery performance, it is recommended that you first use up the battery power and then charge it completely. A new battery's full performance is achieved only after three complete charge and discharge cycles.

1. Connect your travel adapter to the left side of your mobile phone as shown in the diagram.
2. When the battery is being charged, the display will show the animation of a battery being filled up.
3. When the battery is fully charged, disconnect the charger.



Powering your phone on/off

Make sure that the SIM card is in your device and the battery is charged.

Hold the **End/Power key** to power on/off the phone.

Turning the torch on/off

In the idle screen, hold the **0 key** can turn on or off the torch.

Text Input

- Press the **# key** to change the input modes.
- Delete Character: Press the **Right soft key** to clear a character. Hold the **Right soft key** to delete all characters.
- Move cursor to left or right: Among the text, press the **Left/Right navigation keys** to move the cursor to left or right.

Adding contact to the Phonebook

You can save numbers to your Phonebook. Access these numbers quickly and easily.

1. Go to **Menu>Phonebook>Add new contact**.
2. Edit the information and save it.

Making and receiving calls

The most basic way to make a call is to input the number in the standby mode and press the **Send key**. You can also make a call from the Phonebook list.

- To call someone: Go to **Menu> Phonebook**. Use the **Up/Down keys** to find the name of the person you want to call, and press the **Send key**.
- To receive a call, press the **Send key**.
- To end or reject a call, press the **End/Power key**.

Sending and receiving messages

You can use your mobile phone to send and receive messages.

- Send a message
 1. Go to **Menu>Messaging>Write message>Text/Multimedia message**.
 2. Write your message.
 3. When you finish writing an SMS/MMS, select to send or save the message.
- Receive a message

When you receive a new message, pressing **View** to open it. You can also go to Inbox to read the message.

User profiles

Go to **Menu>User profiles**. You can select **Options>Activate** to activate a profile. Or you can select **Options>Customize** to edit a profile.

Call center

Go to **Menu>Call center**.

- Call history

Missed calls, Dialed calls and Received calls are saved in Call history. If the records are full, the earliest saved records will be deleted.

Also, you can delete call logs in Call history.

- Call settings

You can set Call waiting, Call divert, Call barring and so on.

Setting your phone

You can adjust various settings of your phone. Go to **Menu>Settings**.

- Phone settings: Set Time and date, Schedule power on/off, Language and Display, etc.
- Network settings: Set to automatically or manually select network, and set the preferred networks.
- Security settings: Set security features to protect you from unauthorized use of your phone and SIM card.
- Connectivity: Set Bluetooth and Data account.
- Restore factory settings: Input the phone password to restore to the factory settings. Some personal information might be lost if you use this function, so be careful.

Note: You may be required to input the phone password in some of the security settings interfaces. The default password is 1234.

How to take a photo

Go to **Menu>Multimedia>Camera**.

- To take a photo: aim the camera at the object and then press the **Center key** to take the shot.

- Configure camera: press the **Left soft key** to configure your camera.

How to play music

Go to **Menu>Multimedia>Audio player**. You can play the audio in your phone or the memory card.

How to use FM radio

Go to **Menu>Multimedia>FM radio**.

With the radio, you can search for radio channels, listen to them, and save them on your device.

Note: please take your handset as the standard.

Using Services

Go to **Menu>Services**. In Services you can view internet content.

LEGAL INFORMATION

Copyright © 2012 ZTE CORPORATION.

All rights reserved.

No part of this publication may be excerpted, reproduced, translated or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation.

The manual is published by ZTE Corporation. We reserve the right to make modifications on print errors or update specifications without prior notice.

Version No.: R1.0

Edition Time: 2012.10.22