

**ZTE**



**ZTE Grand X**

**Quick Start Guide**

## LEGAL INFORMATION

Copyright © 2012 ZTE CORPORATION.

All rights reserved.

No part of this publication may be quoted, reproduced, translated or used in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation.

ZTE Corporation reserves the right to make modifications on print errors or update specifications in this guide without prior notice.

The *Bluetooth*<sup>®</sup> trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such trademarks by ZTE Corporation is under license. Other trademarks and trade names are the property of their respective owners.

The phone is manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.



We offer self-service for our smart terminal device users. Please visit ZTE official website (at [www.zte.com.cn](http://www.zte.com.cn)) for more information on self-service and supported product models. Information subject to the website.

Version No. : R1.0

Edition Time : 20120508


Manual No. : 079584504570

**Getting to Know Your Phone**




## Starting Up


Removing the back cover



Inserting the SIM card



Inserting the microSD card



**NOTE:** microSD logo  is a trademark of the SD Card Association.



**ZTE**

**ZTE CORPORATION**

NO. 55, Hi-tech Road South, ShenZhen, P.R.China


Postcode: 518057

<http://www.zte.com.cn> [mobile@zte.com.cn](mailto:mobile@zte.com.cn)

Service Hotline: +86-755-25770600

ZTE Customer Services: +44(0)20 3450 8722 0900 783 0094

Installing the battery



Charging the phone



### Powering On/Off Your Phone

Make sure the SIM is in your device and the battery is charged.

- Press and hold the **Power Key** to switch on your phone.
- To switch it off, press and hold the **Power Key** and touch **Power off > OK**.

## Locking/Unlocking the Screen and Keys





Your phone allows you to quickly lock the screen and keys when not in use and to turn the screen back on and unlock it when you need it.

### To lock the screen and keys:

To quickly turn the screen off and lock the keys, press the **Power Key**.

**NOTE:** To save battery power, the phone automatically turns off the screen after a certain period of time when you leave it idle. You will still be able to receive messages and calls while the phone screen is off.













### To unlock the screen and keys:






1. Press the **Power Key** to turn the screen on.
2. Drag  to  to unlock the screen and keys. You can also drag  to  to open the camera and start taking photos immediately.

**NOTE:** If you have set an unlock pattern, PIN or password for your phone, you'll need to draw the pattern or enter the PIN/password to unlock your screen.



### Product Safety Information

	Do not use hand-held while driving		Do not use while re-fuelling
	For body-worn operation maintain a separation of 15 mm		This device may produce a bright or flashing light
	Small parts may cause a choking hazard		Do not dispose of it in a fire
	This device may produce a loud sound		Avoid contact with magnetic media
	Keep away from pacemakers and other personal medical devices		Avoid Extreme Temperatures
	Switch off when instructed in hospitals and medical facilities		Avoid any contact with liquid, keep it dry

	Switch off when instructed in aircrafts and airports		Do not attempt to disassemble
	Switch off in explosive environments		Only use approved accessories
	Do not rely on this device for emergency communications		