

MF190

ZTE

中兴

USB Modem

Quick Guide

ZTE

中兴

MF190

ZTE

Software Installation Guide

On different operating systems, the installation procedures may be different. Follow the system prompts during operation. Various icons are presented to enable quick operation of the following functions:

For Windows OS

Your system will start the software setup process automatically when you connect the modem to your computer correctly. Follow the system prompts to complete the software installation.

Notes:

If the system does not launch installation automatically, you can run the installation program in path of My Computer > ZTEMODEM.

For Mac OS

The system will automatically display a ZTEMODEM CD-ROM icon on the desktop, when you connect the modem to your computer correctly. Double click the installation software package in the ZTEMODEM, and follow the system prompts to complete the software installation.

Safe removal from your system

Please close the application software, and then you can pull out the USB Modem safely.

To the owner

ZTE shall not be liable for any loss of profits or indirect, special, incidental or consequential damages resulting from or arising out of or in connection with using of this product, whether or not ZTE had been advised, knew or should have known of the Product.

How to use your modem

Some electronic devices are susceptible to electromagnetic interference sent by modem if inadequately shielded, such as the electronic system of vehicles. Please consult the manufacturer of the device before using the modem if necessary.

Avoid using the modem near or inside metallic structures or establishments that can emit electromagnetic waves. Otherwise it may influence signal reception.

Operating of laptop and desktop PCs and the modem may interfere with medical devices like hearing aids and pacemakers. The modem is not waterproof. Please keep it dry and store in a shady and cool place.

Power failures, surges, fire, flood, accidents, actions of third parties or other events outside ZTE's reasonable control. Please always keep them more than 20 centimeters away from such medical devices when they are turned on. Turn the modem off if necessary. Consult a physician or the manufacturer of the medical device before using the modem.

Usage of third-party products, or usage in conjunction with third-party products provided that such defects are due to the combined usage. You can get Help by:

Any other cause beyond the range of normal usage intended for the Product.

Be aware of the usage limitation when using a modem at places such as oil warehouses or chemical factories, where there are explosive gases or explosive products being processed. Turn off your modem if required.

Handle the modem carefully. Do not drop, bend or strike it. Otherwise the modem will be damaged. No dismantling by non-professionals and only qualified technicians can undertake repair work.

The use of electronic transmitting devices is forbidden in aircrafts, at petrol stations and in hospitals. Please observe mentioned situations.

Operating temperature range of -10°C ~ +60°C and humidity range of 5% ~ 95% are recommended.

This warranty is End User's sole remedy and ZTE's sole liability for defective or nonconforming items, and is in lieu of all other warranties, expressed, implied or statutory, including but not limited to the implied warranties of merchantability and fitness for a particular purpose, unless otherwise required under the mandatory provisions of the law.

This warranty does not apply to defects or errors in the Product caused by:

i. Reasonable abrasion.

Using your USB Modem

Please use original accessories or accessories that are authorized. Using any unauthorized accessories may affect

ZTE's performance, and violate related national regulations about telecom terminals.

Avoid using the modem near or inside metallic structures or establishments that can emit electromagnetic waves. of the possibility of such damages, including, but not limited to lost profits, interruption of business, cost of capital, cost of

Otherwise it may influence signal reception.

Power failures, surges, fire, flood, accidents, actions of third parties or other events outside ZTE's reasonable control. Please always keep them more than 20 centimeters away from such medical devices when they are turned on. Turn the modem off if necessary. Consult a physician or the manufacturer of the medical device before using the modem.

Usage of third-party products, or usage in conjunction with third-party products provided that such defects are due to the combined usage. You can get Help by:

Any other cause beyond the range of normal usage intended for the Product.

Be aware of the usage limitation when using a modem at places such as oil warehouses or chemical factories, where

there are explosive gases or explosive products being processed. Turn off your modem if required.

Handle the modem carefully. Do not drop, bend or strike it. Otherwise the modem will be damaged. No dismantling by non-professionals and only qualified technicians can undertake repair work.

The use of electronic transmitting devices is forbidden in aircrafts, at petrol stations and in hospitals. Please observe

mentioned situations.

Operating temperature range of -10°C ~ +60°C and humidity range of 5% ~ 95% are recommended.

This warranty is End User's sole remedy and ZTE's sole liability for defective or nonconforming items, and is in lieu

of all other warranties, expressed, implied or statutory, including but not limited to the implied warranties of merchantability and fitness for a particular purpose, unless otherwise required under the mandatory provisions of the law.

This warranty does not apply to defects or errors in the Product caused by:

i. Reasonable abrasion.

Warning and Notice

End User's failure to follow ZTE's installation, operation or maintenance instructions or procedures.

ZTE shall not be liable for any loss of profits or indirect, special, incidental or consequential damages resulting from or

arising out of or in connection with using of this product, whether or not ZTE had been advised, knew or should have known of the Product.

Some electronic devices are susceptible to electromagnetic interference sent by modem if inadequately shielded, such as the electronic system of vehicles. Please consult the manufacturer of the device before using the modem if necessary.

Avoid using the modem near or inside metallic structures or establishments that can emit electromagnetic waves. of the possibility of such damages, including, but not limited to lost profits, interruption of business, cost of capital, cost of

Otherwise it may influence signal reception.

Power failures, surges, fire, flood, accidents, actions of third parties or other events outside ZTE's reasonable control. Please always keep them more than 20 centimeters away from such medical devices when they are turned on. Turn the modem off if necessary. Consult a physician or the manufacturer of the medical device before using the modem.

Usage of third-party products, or usage in conjunction with third-party products provided that such defects are due to the combined usage. You can get Help by:

Any other cause beyond the range of normal usage intended for the Product.

Be aware of the usage limitation when using a modem at places such as oil warehouses or chemical factories, where

there are explosive gases or explosive products being processed. Turn off your modem if required.

Handle the modem carefully. Do not drop, bend or strike it. Otherwise the modem will be damaged. No dismantling by non-professionals and only qualified technicians can undertake repair work.

The use of electronic transmitting devices is forbidden in aircrafts, at petrol stations and in hospitals. Please observe

mentioned situations.

Operating temperature range of -10°C ~ +60°C and humidity range of 5% ~ 95% are recommended.

This warranty is End User's sole remedy and ZTE's sole liability for defective or nonconforming items, and is in lieu

of all other warranties, expressed, implied or statutory, including but not limited to the implied warranties of merchantability and fitness for a particular purpose, unless otherwise required under the mandatory provisions of the law.

i. Reasonable abrasion.

Limitation of Liability

To the owner

ZTE shall not be liable for any loss of profits or indirect, special, incidental or consequential damages resulting from or

arising out of or in connection with using of this product, whether or not ZTE had been advised, knew or should have known of the Product.

Some electronic devices are susceptible to electromagnetic interference sent by modem if inadequately shielded, such as the electronic system of vehicles. Please consult the manufacturer of the device before using the modem if necessary.

Avoid using the modem near or inside metallic structures or establishments that can emit electromagnetic waves. of the possibility of such damages, including, but not limited to lost profits, interruption of business, cost of capital, cost of

Otherwise it may influence signal reception.

Power failures, surges, fire, flood, accidents, actions of third parties or other events outside ZTE's reasonable control. Please always keep them more than 20 centimeters away from such medical devices when they are turned on. Turn the modem off if necessary. Consult a physician or the manufacturer of the medical device before using the modem.

Usage of third-party products, or usage in conjunction with third-party products provided that such defects are due to the combined usage. You can get Help by:

Any other cause beyond the range of normal usage intended for the Product.

Be aware of the usage limitation when using a modem at places such as oil warehouses or chemical factories, where

there are explosive gases or explosive products being processed. Turn off your modem if required.

Handle the modem carefully. Do not drop, bend or strike it. Otherwise the modem will be damaged. No dismantling by non-professionals and only qualified technicians can undertake repair work.

The use of electronic transmitting devices is forbidden in aircrafts, at petrol stations and in hospitals. Please observe

mentioned situations.

Operating temperature range of -10°C ~ +60°C and humidity range of 5% ~ 95% are recommended.

This warranty is End User's sole remedy and ZTE's sole liability for defective or nonconforming items, and is in lieu

of all other warranties, expressed, implied or statutory, including but not limited to the implied warranties of merchantability and fitness for a particular purpose, unless otherwise required under the mandatory provisions of the law.

i. Reasonable abrasion.

Table of Contents