USB Modem

Quick Guide

IF1	9	N	L	_



-1	a	n	ı	ı	

WII 1300









































The ZTE USB modem is a multi-mode USB modem, working in HSUPA/HSDPA/WCDMA/EDGE/GPRS/GSM Dimension networks. With USB interface connecting to a laptop or a desktop PC, it integrates the functionality of a modem and a mobile phone (SMS), and combines mobile communication with Internet perfectly. It supports data and SMS services through the mobile phone network, enabling you to communicate anytime and anywhere. Specification

Introduction

The following table shows the specification of your device.

ing table shows the specimoation of your device.				
Гуре	USB 2.0 HIGH SPEED			
supported	Supports most types of laptop and desktop PC.			
systems supported	Windows XP, Vista, Windows 7 MAC 10.4, 10.5, 10.6			
	SMS service, Data service, Applications management, support microSD card, etc.			
Standards	HSUPA/HSDPA/WCDMA/EDGE/GPRS/GSM			
sion speed (Max)	HSUPA: 5.76 Mbps UL HSDPA: 7.2 Mbps DL			

Storage: -40°C ~ +80°C Operation:-10°C ~ +55°C Temperature 90 mm×27 mm×10.5 mm nicroSD capability Support up to 32 GB microSD card

Notes: microSD Micro is a trademark of SD Card Association.

Getting to know your device The following figure shows the appearance of the MF190U. It is only for your reference. The actual product may



be different.





- Indicato
- Front Cover
- SIM/USIM card slot

- Modem Cap
- microSD card slot
- USB Connector

Hardware Installation

Slide the front cover and remove it.

Do not remove the front cover rudely so as to avoid the damage of the front cover.

Insert the SIM/USIM card into the SIM/USIM card slot.




. Insert the microSD card into the microSD card slot. Notes: This modem only supports microSD card. Insert your microSD card into the microSD card slot, shown as the following

- 4. Slide the back cover and lock the cover in its place.

starts the installation wizard.

- . Connect the Modem to your laptop or desktop PC.
- Plug the USB connector into your computer's USB port and make sure that it is tightly inserted.
- > The OS automatically detects and recognizes new hardware and



Copyright © 2011 ZTE CORPORATION.

No part of this publication may be excerpted, reproduced, translated or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE

The manual is published by ZTE Corporation. We reserve the right to make modifications on print errors or

update specifications without prior notice.

LEGAL INFORMATION

Version No.: R1.0

ZTE CORPORATION

NO. 55. Hi-tech Road South, ShenZhen, P.R.China

Postcode: 518057

Software Installation Guide

On different operating systems, the installation procedures may be difference. Follow the system promots during

For Windows OS

Your system will start the software setup process automatically when you connect the modem to your computer correctly. Follow the system prompts to complete the software installation.

If the system does not launch installation automatically, you can run the installation program in path of My

Computer > ZTEMODEM.

For Mac OS

The system will automatically display a ZTEMODEM CD-ROM icon on the desktop, when you connect the modem to your computer correctly. Double click the installation software package in the ZTEMODEM. and follow the system prompts to complete the software installation.

Safe removal from your system Please close the application software, and then you can pull out the USB Modem safely.

How to use your modem

Various icons are presented to enable quick operation of the following functions:

	③	Connect	Connect to the Internet.
	\bowtie	SMS	Click the New button, enter recipient's number and content, and then click the Send button to send new message.
Phonebook Click the New but		Phonebook	Click the New button to fill in a new contact person and contact details.
	Settings		Set the configuration for the USB modem.
Data records		Data records	Show the connection information.

To the owner

Warning and Notice

- Some electronic devices are susceptible to electromagnetic interference sent by modem if inadequately shielded, such as the electronic system of vehicles. Please consult the manufacturer of the device before
- using the modem if necessary. Operating of laptop and desktop PCs and the modern may interfere with medical devices like hearing aids and pacemakers. Please always keep them more than 20 centimeters away from such medical devices
- medical device before using the modem. Be aware of the usage limitation when using a modem at places such as oil warehouses or chemical factories, where there are explosive gases or explosive products being processed. Turn off your modem if
- The use of electronic transmitting devices is forbidden in aircrafts, at petrol stations and in hospitals. Please

when they are turned on. Turn the modem off if necessary. Consult a physician or the manufacturer of the

- observe and obey all warning signs and switch off your modem in these conditions.
- Do not touch the inner antenna area if not necessary. Otherwise it will affect your modem's performance.
- Store the modem out of the reach of little children. The modem may cause injury if used as a toy.
- Do not touch the metallic parts of the modem so as to avoid a burn, when the modem is working.

Using your USB Modem

- Please use original accessories or accessories that are authorized. Using any unauthorized accessories may affect your modem's performance, and violate related national regulations about telecom terminals.
- Avoid using the modem near or inside metallic structures or establishments that can emit electromagnetic
- waves. Otherwise it may influence signal reception.
- The modem is not waterproof. Please keep it dry and store in a shady and cool place.
- Do not use the modern immediately after a sudden temperature change. In such case, it will produce dev
- inside and outside the modem, so don't use it until it becomes dry. Handle the modern carefully. Do not drop, bend or strike it. Otherwise the modern will be damaged.
- No dismantling by non-professionals and only qualified technicians can undertake repair work.
- Operating temperature range of -10°C ~ +60°C and humidity range of 5% ~ 95% are recommended.

- Limited Warranty

operation of the Product.

- This warranty does not apply to defects or errors in the Product caused by:
- Reasonable abrasion.

- End User's failure to follow ZTE's installation, operation or maintenance instructions or procedures.
- iii. End User's mishandling, misuse, negligence, or improper installation, disassembly, storage, servicing of

- v. Modifications or repairs not made by ZTE or a ZTE-certified individual.
- . Power failures, surges, fire, flood, accidents, actions of third parties or other events outside ZTE's reasonable control.
- vi. Usage of third-party products, or usage in conjunction with third-party products provided that such defects are due to the combined usage.
- vii. Any other cause beyond the range of normal usage intended for the Product.
- End User shall have no right to reject or return the Product, or receive a refund for the Product from 7TF under the above-mentioned situations.
- This warranty is End User's sole remedy and ZTE's sole liability for defective or nonconforming items, and is in lieu of all other warranties, expressed, implied or statutory, including but not limited to the implied warranties of merchantability and fitness for a particular purpose, unless otherwise required under the mandatory provisions of the law.

Limitation of Liability ZTE shall not be liable for any loss of profits or indirect, special, incidental or consequential damages resulting from or arising out of or in connection with using of this product, whether or not ZTE had been advised, knew or should have known of the possibility of such damages, including, but not limited to lost profits, interruption of business, cost of capital, cost of substitute facilities or product, or any downtime cost,

How to get help You can get Help by

- Clicking **Help** on the software.
- Sending E-mail to mobile@zte.com.cn
- Visiting http://www.zte.com.cn
- Calling Service Hotline: +86–755–26779999