

MF190A

## LEGAL INFORMATION Introduction

Copyright © 2010 ZTE CORPORATION.

All rights reserved.

Version No.: R1.0

No part of this publication may be excerpted, reproduced, translated or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written **USB Modem** permission of ZTE Corporation.

**Quick Guide** 

The manual is published by ZTE Corporation. We reserve the right to make modifications on print errors or update specifications without prior notice.

communicate anytime and anywhere.

Specification	
The following table shows the specification of your device.	
Interface Type	USB 2.0 HIGH SPEED
Systems supported	Supports most types of laptop and desktop PC.
( )nerating systems supported	Windows XP(SP2 or later), Vista(32bit or 64bit), Windows 7
	MAC 10.4 or later
Functions	SMS service, Data service, Applications management, etc.
Network Standards	HSUPA/HSDPA/WCDMA/EDGE/GPRS/GSM


GPRS/GSM networks. With USB interface connecting to a laptop or a desktop PC, it integrates the

functionality of a modem and a mobile phone (SMS), and combines mobile communication with Internet

perfectly. It supports data and SMS services through the mobile phone network, enabling you to

## HSUPA: 5.76Mbps UI HSDPA: 7.2Mbps DL Storage: -40°C ~ +80°C Operation:-10°C ~ +60°C 77.9mm×27mm×10.8mm(without cap)

The following figure shows the appearance of the MF190A. It is only for your reference. The actual product may be different.



. USB Connector

- Indicator
- 2. Front Cover
- 3. SIM/USIM card slot

1. Put finger on the bottom finger grip, and then lift the front cover of the modem to release and remove.



**Notes**: Do not open the front cover rudely to avoid the damage of the front cover. Insert the SIM/USIM card.

ZTE CORPORATION Insert the SIM/USIM card with the metal contact area facing downwards into the slot, shown as the NO. 55, Hi-tech Road South, Shenzhen, P.R.China following picture.

Postcode: 518057 http://www.zte.com.cn mobile@zte.com.cn

ZTE中兴

Service Hotline: +86-755-26779999

The information on the package is only for your reference, Images are for your reference only.

Please check the product model before purchasing.

ZTE reserves the rights to change specifications and parameters of the products without further notice

**C € 1588** 

# The ZTE USB modem is a multi-mode USB modem, working in HSUPA/HSDPA/WCDMA/EDGE/

. Close the front cover as shown in the following picture.



- Connect the Modem to your laptop or desktop PC.
- Plug the USB connector into your computer's USB port and make sure that it is tightly inserted.







The OS will automatically recognize the new hardware and start the installation wizard.

## Warning and Notice

- Some electronic devices are susceptible to electromagnetic interference sent by modem if inadequately shielded, such as the electronic system of vehicles. Please consult the manufacturer of the device before using the modem if necessary.
- Operating of laptop and desktop PCs and the modem may interfere with medical devices like hearing aids and pacemakers. Please always keep them more than 20 centimeters away from such medical devices when they are turned on. Turn the modem off if necessary. Consult a physician or
- the manufacturer of the medical device before using the modem. Be aware of the usage limitation when using a modem at places such as oil warehouses or chemical factories, where there are explosive gases or explosive products being processed. Turn off your modem if required.
- The use of electronic transmitting devices is forbidden in aircrafts, at petrol stations and in hospitals. Please observe and obey all warning signs and switch off your modem in these conditions.

- Do not touch the inner antenna area if not necessary. Otherwise it will affect your modem's
- Store the modem out of the reach of little children. The modem may cause injury if used as a toy.
- Do not touch the metallic parts of the modem so as to avoid a burn, when the modem is working

performance.

- Please use original accessories or accessories that are authorized. Using any unauthorized accessories may affect your modem's performance, and violate related national regulations about telecom terminals.
- Avoid using the modem near or inside metallic structures or establishments that can emit electromagnetic waves. Otherwise it may influence signal reception.
- The modem is not waterproof. Please keep it dry and store in a shady and cool place.
- Do not use the modern immediately after a sudden temperature change. In such case, it will
- produce dew inside and outside the modem, so don't use it until it becomes dry.
- Handle the modem carefully. Do not drop, bend or strike it. Otherwise the modem will be damaged.

- No dismantling by non-professionals and only qualified technicians can undertake repair work.
  - Operating temperature range of -10°C ~ +60°C and humidity range of 5% ~ 95% are recommende
  - This warranty does not apply to defects or errors in the Product caused by:

  - Reasonable abrasion. i. End User's failure to follow ZTE's installation, operation or maintenance instructions or
  - procedures.
  - iii. End User's mishandling, misuse, negligence, or improper installation, disassembly, storage, servicing or operation of the Product.

  - v. Modifications or repairs not made by ZTE or a ZTE-certified individual.

  - Power failures, surges, fire, flood, accidents, actions of third parties or other events outside
  - ZTE's reasonable control. vi. Usage of third-party products, or usage in conjunction with third-party products provided that
  - such defects are due to the combined usage.

vii. Any other cause beyond the range of normal usage intended for the Product.

End User shall have no right to reject or return the Product, or receive a refund for the Product from ZTE under the above-mentioned situations.

This warranty is End User's sole remedy and ZTE's sole liability for defective or nonconforming items, and is in lieu of all other warranties, expressed, implied or statutory, including but not limited

required under the mandatory provisions of the law.

resulting from or arising out of or in connection with using of this product, whether or not ZTE had been

advised, knew or should have known of the possibility of such damages, including, but not limited to lost

profits, interruption of business, cost of capital, cost of substitute facilities or product, or any downtime

ZTE shall not be liable for any loss of profits or indirect, special, incidental or consequential damages

to the implied warranties of merchantability and fitness for a particular purpose, unless otherwise

You can get Help by:

How to get help

- - Clicking Help on the software.
  - Sending E-mail to mobile@zte.com.cn
  - Visiting http://www.zte.com.cn
  - Calling Service Hotline: +86–755–26779999